ULTRAFIT™

Product Care Guide

Paint Protection Film

Your vehicle has been fitted with ULTRAFIT Paint Protection Film (PPF).
Please follow the care instructions below to keep the film looking and performing at its best.

Maintaining Optimal Protection and Appearance

Use gentle, proper care methods to keep the film looking and performing at its best.

1 7 DAYS After Installation

No washing for 48 hours

Avoid washing the vehicle for the first 48 hours after installation.

Do not touch the edges

Do not press, rub, or peel at the edges of the film.

Allow time to settle

Allow enough time for the film to fully settle.

NOTE **Small moisture marks or slight haziness** may appear after installation; these will generally clear up naturally as the film fully dries and settles.

2 General Washing

RECOMMENDED	AVOID
✓ **Hand washing** is recommended whenever possible.	✗ Coarse brushes
✓ Use a **pH-neutral automotive shampoo** with a clean microfiber wash mitt.	✗ Harsh chemical cleaners
✓ Rinse away **dust and debris with plenty of water** before washing.	✗ Spraying directly at edges or seams
✓ If using a pressure washer, keep a **safe distance** from the film.	

3 Clean IMMEDIATELY

Remove as soon as possible

Bird droppings · Bug residue
Tree sap · Road tar

And any other contaminants, as soon as possible.

- ✓ For stubborn contaminants, soak thoroughly with water or **a suitable automotive cleaner** before gently wiping away.
- ✗ Do not **scrub or scrape** the film to remove contaminants.

4 Drying

Gently remove water from the film's surface.

Use a clean, soft **microfiber towel** or an **automotive air blower.**

When drying near the edges, wipe **along the direction of the edge** rather than against it.

5 Wax and Detailing Products

RECOMMENDED

- ✓ Use automotive care products that are **safe for use with PPF.**
- ✓ For **matte or satin PPF**, use products formulated specifically for matte/satin finishes.

AVOID

- ✕ Compounds or polishes containing abrasives
- ✕ Strong solvents or chemical cleaners
- ✕ Strong dyes or staining ingredients
- ✕ Excessive machine polishing

6 Pressure Washing

Keep a sufficient distance

Pressure washing is safe for the film when done correctly. Keep a distance of at least 3ft (1m) from the film's surface.

No strong, direct spray

Do not spray strong, direct pressure at the film's edges, seams, corners, or any existing damage.

7 Self-Healing

20-30 MIN

Heals at room temperature

Light scratches will generally heal naturally within about 20–30 minutes at room temperature.

49°C 120°F

Warm water speeds it up

In cooler weather, or to speed up healing, applying warm water at about 49°C (120°F) to the scratched area can help.

8 If a Problem Occurs

✕ Do not **pull, cut, trim, remove,** or **attempt to reinstall** the film yourself.

NOTE If you notice **lifting along the film edges, discoloration, bubbles, or any other damage,** please contact an **ULTRAFIT Authorized Dealer immediately** for inspection.